ACCESSORY SETS





SET 38 HF

Item No. 602071

Material moisture supplement set for GMH 3831/51 (without device), wood moisture

CONTENT:

- GKK 3500 (case)
- GMK 38 (measuring cable)
- · GSE 91 (impact electrode)
- GST 91 (measuring pins)
- GTF 38 (temperature probe)

USAGE:

Wood





SFT 38 BF

Item No. 602073

Material moisture supplement set for GMH 3831/51 (without device), wood and building moisture

CONTENT:

- GKK 3500 (case)
- GMK 38 (measuring cable)
- GSE 91 (impact electrode)
- GST 91 (measuring pins)
- GTF 38 (temperature probe) • GMS 300/91 (measuring rods)
- GBSK 91 (wire brush probes)
- GLP 91 (conductive paste)

USAGE:

Wood, concrete, screed, plaster





SET 38 MPA

Item No. 602075

Material moisture supplement set for GMH 3831/51 (without device), MPA wood moisture, accessories as tested by MPA for glued wood construction requiring approval

CONTENT:

- GKK 3500 (case)
- GMK 38 (measuring cable)
- GHE 91 (Reciprocating piston electrode)
- GST 91 (measuring pins)
- GTF 38 (temperature probe)

USAGE:

Wood, glued wood construction, production of glued laminated timber

MATERIAL MOISTURE COMPLETE SET



GMH 38-LW1-TF

Item No. 606470

GMH 38-LW1-TFK

Item No. 606462

GMH 38-LW2-TF

Item No. 606471

GMH 38-LW2-TFK

Item No. 606463

Moisture measurement set for agriculture

GENERAL:

Measuring instrument for fast material moisture determination in bales and bulk goods. Universally applicable aid for damage prevention and quality assurance. The over 1 m long probe with integrated temperature probe is very well suited for measurements in hay and straw bales as well as bulk material. By penetration the material to be measured, moisture and temperature can be determined quickly and easily.

APPLICATIONS:

- · Hav. flax
- · Straw, grain
- Wood chips • Wheat
- Barley

A simplified moisture assessment is carried out in 9 stages.

TECHNICAL SPECIFICATIONS:

GMH 3831 or GMH 3851 Insertion probe: GSF 50, GSF 50K, GSF 50TF, GSF 50TFK scope of delivery GMH 38-LW1-TF: GMH 3831, GSF 50 TF, battery, operating instructions GMH 38-LW1-TFK: GMH 3831, GSF 50 TFK, battery, operating instructions GMH 38-LW2-TF: GMH 3851, GSF 50 TF, battery, operating instructions **GMH 38-LW2-TFK:** GMH 3851, GSF 50 TFK, battery, operating instructions